

ROXOR GOLF

Control Box

MAP: Shows an overview of hole with distance markers

TARGET: Shows where your current shot should theoretically land

MULLIGAN: Lets you take a Re-Do of the last shot


FLYOVER: Gives a complete flyover of the current hole

ENTER/DROP: If ball hit out of bounds or in water, utilize this to enter your final placement

LEFT: Aim/move to Left

RIGHT: Aim/move to Right

CLUB UP/DOWN: change the desired club you want to use for the current shot



FOR IMMEDIATE ASSISTANCE CALL
585-469-8765

